

Equa 2® Chairs



COMFORT FOR ALL

Equa, as in equal, as in equal and equitable seating for everyone. That was the goal that drove Bill Stumpf and Don Chadwick to design the Equa® chair. They wanted to create a chair that would bring ergonomic comfort to everybody in the office—whatever their role, wherever their work space. They did it, and called it Equa, a chair that responds naturally, simply, and ergonomically. *Time* magazine chose it as a Design of the Decade. All kinds of people choose it for the places where they work.





ADJUSTING THE EQUA 2 CHAIR

Active adjustments give people control over their own comfort and support.

1. Seat height – A pneumatic adjustment lowers seat height to 15½ inches on A- and B-size chairs and rises to 22½ inches on the C size.
2. Tilt lock – This secures the work chair in an upright position for task-intensive postures.
3. Armrest height and angle – Each arm adjusts vertically in a 4-inch range and laterally up to ¾ inch. Armrests pivot up to 25 degrees for forearm support while keyboarding and mousing.
4. Lumbar support – Pressing the activator on the front side of the shell inflates a lumbar device, which also moves to adjust the fit (4-inch range on B and C sizes, 3-inch range on A size).
5. Tilt tension – This adjusts the amount of resistance felt when leaning back in the chair. Stools also have a tilt option.

FLEXIBLE, CONTINUOUS SUPPORT

The seat and back of the patented one-piece Equa shell flex separately to give continuous, natural support no matter the posture. The opening between the seat and back allows air to circulate, relieving heat that can build up as you sit.

NO-PRESSURE PIVOT

The knee-tilt mechanism creates a pivot point near the knee, allowing feet to stay on the floor as you lean back. This eliminates pressure on the underside of the thighs and promotes circulation.





THREE SIZES FOR THE RIGHT FIT

Equa 2 work chairs come in three sizes. The B size fits the majority of people. The A size is made for the smaller and lighter, the C size for the taller and heavier.



Bill Stumpf



Don Chadwick



Equa 2 Work Chair



Equa 2 Side Chair




Equa 2 Stool

The one-piece Equa shell is composed of a strong yet flexible plastic permeated with color to reduce fading and make minor scratches unnoticeable. Equa 2 components are composed primarily of recycled materials.

12-YEAR, 3-SHIFT WARRANTY

Like all Herman Miller products, the Equa 2 chair is durable for long-term performance and value. As a statement of our confidence in its quality, the Equa 2 chair is covered by the Herman Miller Warranty—a straightforward promise that we stand behind that quality 100 percent. The 12-year, 3-shift warranty covers all standard elements and includes labor on all warranty work.

For more information about our products and services or to see a list of dealers, please visit us at www.HermanMiller.com or call (800) 851 1196.

© 2003 Herman Miller, Inc. Zeeland, Michigan Printed in U.S.A. O.MS2320-6
®  Herman Miller, Equa, and Equa 2 are among the registered trademarks of Herman Miller, Inc.